

Wool Wrap Lanolising Guide



Put lukewarm water in a bowl. Ideally around 25°C. Never hotter than 30°C.



Rub wool soap into your hands so that the water becomes a bit cloudy.



Take about a pea sized amount of pure lanolin.



Melt it in the microwave or by using boiling water.



Pour it into your soapy water and stir. It should go very cloudy.



Soak your cover for 20 minutes (for the first few treatments it needs at least 8 hours), no need to rinse.

Gently squeeze excess water with a clean towel and air dry on a flat surface